


Cabinet Installation

- It is easiest to flip table surface upside down.
- Position Marty on left or right underside of worksurface in the desired location. Typically the unit is installed inset $\frac{1}{2}$ " from the leg and front table edge.
- Attach Marty to worksurface using a #2 Phillips driver and (4) 1" self-drilling screws provided.
- Return table to upright position.
- Insert provided small plastic hole plug on opposing side of bottom hinge.
- Install coat/bag hook conveniently in one of several designated slots.


Tools Required



Power Drill



#2 Phillips



Tape Measure



#10 x 1" Self-drilling Screw



Hole Plug



Coat/Bag Hook

Kit Contents